

[NIKO BOX PACKING METHOD]



Inner bore < 90mm, we use individual  
small box packing.

For example,

NIKO 81208 TV , it means 1x1 individual small box packing.

PAGES

3 ~ 5

Concerning the model number without remark(OEM1), Inner bore < 90mm, use individual small box packing./ 1x1 packing, please refer to (A)-(G)

For example,  
NIKO 81208 TV, it means 1x1 individual small box packing.

**PACKING METHOD: 1 x 1**

(A): Put the bearing into the suitable small plastic bag;



(B): Paste the model label on the small box;



(C): Put it into the suitable small box according to step one;



(D): Paste tape for small box, individual small box packing finished;



(E): Put the individual small boxes packing into the carton, carton plastic bag has been in the carton (including big and small cartons, bearing outer diameter  $\leq 40\text{mm}$  have used small carton, the others big carton);



(F): Envelop the carton, and paste tape for outer carton;



(G): Put all the cartons on the pallet, then covered with pallet surrounding paper-cartons to make sure the shipment fixedness;



Final packing effect is finished;

